


INSTALLATION INSTRUCTIONS

For

OCL DASH WALL SCNCE



DA1-S1SC-50-MW-BTP

These instructions cover the following fixtures & options:

-Dash series standalone sconce 2'- 6' length.

GENERAL NOTES:

-PLEASE COMPLETELY READ THE INSTALL INSTRUCTIONS BEFORE STARTING INSTALLATION.

-INSTALL IN ACCORDANCE WITH ALL LOCAL, STATE AND NATIONAL CODES CONSULT WITH A QUALIFIED ELECTRICIAN FOR PROPER INSTALLATION.

-CAREFULLY UNPACK ALL CONTENTS; SOME COMPONENTS MAY HAVE BEEN SHIPPED IN SEPARATE BOXES. MOST FIXTURES ARE SHIPPED PARTIALLY ASSEMBLED. SOME UNASSEMBLY MAY BE REQUIRED FOR INSTALLATION.

OCL Architectural Lighting

Phone: 314.863.1895

Fax: 314.863.3278

www.ocl.com

DASH SCNCE INSTALLATION INSTRUCTIONS


GENERAL INFORMATION:

You will receive the following with each Dash series sconce fixture:

1. Pre-assembled Dash fixture.
2. Remote driver housing with driver installed.
3. Installation instructions- **Please completely read the install instructions before starting installation.**

WARNING: This fixture should be installed by a licensed electrician only.

FIXTURE DIAGRAM:



OCL Architectural Lighting

Phone: 314.863.1895


Fax: 314.863.3278

www.ocl.com

DASH SCNCE INSTALLATION INSTRUCTIONS

REMOTE DRIVER HOUSING INSTALLATION:


1. Shut off power.
2. Remove the lid from the remote driver housing.
3. Mount the driver housing to code at a location that is accessible after the installation. Max wire length is 20ft measured from the fixture body to the driver.
4. Run a positive and negative 16-20 gage wire (by others) from the remote driver housing to the junction box. Inside the remote driver housing, connect:
 - Driver LED output (+) and positive 16-20 gage wire.
 - Driver LED output (-) and negative 16-20 gage wire.
 - Dimming wires as shown on the driver.
5. Connect building supply wires to the driver. Install the lid on the remote driver housing.



WALL ANCHOR INSTALLATION:

1. Mark center location on wall according to the table below. **Make sure mark is level with the center of the junction box.**
2. Drill 5/8" hole at least 1" deep at the marked location to provide clearance for all thread and nut.
3. Install 4 anchor bodies (by others) in the wall at the locations shown on the drawing below. Make sure that the wall anchors are strong enough to support at least 50lbs. Some wall materials may require reinforcement material.

FIXTURE LENGTH	MOUNTING DISTANCE
26.75"	25.75"
38.75"	37.75"
50.75"	49.75"
62.75"	61.25"
74.75"	73.75"



OCL Architectural Lighting

Phone: 314.863.1895


Fax: 314.863.3278

www.oclighting.com

DASH SCONCE INSTALLATION INSTRUCTIONS

FIXTURE MOUNTING:


1. Turn off power.
2. Loosen the slip ring and slide the canopy toward the fixture body (on both sides), being careful not to scratch the finish of the fixture.
3. With a person at each end of the fixture, attach one end to the junction box and the other end to the anchors installed earlier (hardware by others.)
4. Make wire connections in the junction box. **Make wire connections in accordance with all local, state, and national codes.**
 - Fixture wires:
 - Red wire is (+)
 - Blue wire is (-)
5. Slide the canopies and slip rings down the arms until tight against the wall. Tighten slip ring set screws to hold them in place.



6. Restore power.

FIXTURE AIMING:

1. Loosen both set screws (using a 1/16 Allen wrench) on the endcaps by ½ half turn (do not remove the set screws).
2. Rotate fixture body to desired angle.
3. Tighten the set screws.



OCL Architectural Lighting

Phone: 314.863.1895

Fax: 314.863.3278

www.ocl.com

DASH SCONCE INSTALLATION INSTRUCTIONS