


INSTALLATION INSTRUCTIONS

INSTALL IN ACCORDANCE WITH ALL LOCAL, STATE AND NATIONAL CODES
CONSULT WITH A QUALIFIED ELECTRICIAN FOR PROPER INSTALLATION.

CAREFULLY UNPACK ALL CONTENTS, SOME COMPONENTS MAY HAVE BEEN
SHIPPED IN SEPARATE BOXES. MOST FIXTURES ARE SHIPPED PARTIALLY ASSEMBLED.
SOME DISASSEMBLY MAY BE REQUIRED FOR INSTALLATION.

**PLEASE THOROUGHLY READ
ENTIRE INSTALLATION INSTRUCTIONS
BEFORE BEGINNING**




1. TURN OFF POWER TO CIRCUIT THAT THE FIXTURE IS BEING INSTALLED ON.
2. BREAK OFF THE MOUNTING TABS ON THE 2.125" DEEP 4X4 JUNCTION BOX (REQUIRED - BY OTHERS) TO MAKE ROOM FOR THE STRUCTURAL YOKE TO BE MOUNTED IN THE JUNCTION BOX. SEE DETAIL A.
3. 2 MOUNTING OPTIONS (SEE SHEET TWO FOR DETAIL VIEWS):


MOUNTING OPTION 1: INSTALL TWO 1/4-20 THREADED RODS (BY OTHERS) TO A STRUCTURAL MEMBER DESIGNED TO HOLD THE WEIGHT OF THE FIXTURE. THESE THREADED RODS SHOULD LINE UP WITH THE 0.281" THROUGH HOLES IN THE STRUCTURAL YOKE (SEE SHEET 2 DETAIL B FOR HOLE SPACING) AND PROTRUDE INTO THE 2.125" DEEP JUNCTION BOX BETWEEN 0.75" AND 1.5" (SEE SHEET 2 DETAIL C). MOUNT THE STRUCTURAL YOKE TO THE THREADED RODS WITH APPROPRIATE HARDWARE (BY OTHERS). ATTACH PROVIDED SAFETY CABLE TO STRUCTURAL MEMBER AND RUN INTO THE JUNCTION BOX.

MOUNTING OPTION 2: INSTALL STRUCTURAL CHANNEL (BY OTHERS) RATED FOR THE WEIGHT OF THE FIXTURE DIRECTLY ON TOP OF THE 2.125" DEEP JUNCTION BOX. BOLT THE STRUCTURAL YOKE TO THE CHANNEL USING AT LEAST A 3/8" DIAMETER BOLT (BY OTHERS) THROUGH THE CENTER HOLE OF THE STRUCTURAL YOKE (SEE SHEET 2 DETAIL D). ATTACH PROVIDED SAFETY CABLE TO STRUCTURAL MEMBER AND RUN INTO THE JUNCTION BOX.


CONTINUED ON SHEET 2




MOUNTING HOLE OPTIONS
ON STRUCTURAL YOKE
DETAIL B



DETAIL F



MOUNTING OPTION 1
DETAIL C



MOUNTING OPTION 2
DETAIL D

CONTINUED FROM SHEET 1:

4. LOOSEN CANOPY AND SLIDE DOWN STEM BY ROTATING THE CANOPY 90 DEGREES COUNTER CLOCKWISE. BE CAREFUL NOT TO DAMAGE THE FINISH OF THE FIXTURE.
5. INSTALL THE STEM ASSEMBLY TO THE STRUCTURAL YOKE WITH 1/4-20 HARDWARE. ATTACH THE FIXTURE SAFETY CABLE TO THE SAFETY CABLE THAT WAS INSTALLED PREVIOUSLY WITH PROVIDED THREADED CONNECTOR.
6. MAKE WIRE CONNECTIONS BETWEEN THE FIXTURE WIRES AND THE BUILDING SUPPLY WIRES, MAKING SURE THAT ALL THE GROUND WIRES ARE CONNECTED. MAKE ALL WIRE CONNECTIONS IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND APPLICABLE LOCAL AND STATE CODES. SEE FIXTURE SPECIFIC INSTALL SHEET FOR WIRING DIAGRAM.
7. RAISE THE CANOPY AND TIGHTEN ONTO THE MOUNTING BRACKET BY LINING THE SPRING TABS UP WITH THE NOTCHES IN THE MOUNTING BRACKET AND ROTATING 90 DEGREES CLOCKWISE. SEE DETAIL F ABOVE.