

INSTALLATION INSTRUCTIONS

GLOWBALL PENDANT WITH P1CF HANGING SYSTEM

These instructions cover the GLOWBALL luminaire with the following options:

SERIES	HANGING SYSTEM	SIZE	LIGHT SOURCE	CONTROL	WIRE DIAGRAM
1. GB1(GLOWBALL)	P1CF: PENDANT WITH 5.75" SURFACE MOUNT CANOPY, SINGLE SILVER POWER CORD; MOUNTS TO 4X4 OCTAGON J-BOX (BY OTHERS)	04"	STATIC WHITE	0-10V DIM 1% (DM1)	WIRE DIAGRAM ON PAGE 6




FIG. 1- GB1-P1CF-04-FS-XXX-LED1_XXK-UNV-XXX-DM1

GENERAL NOTES:

1. PLEASE COMPLETELY READ THE INSTALL INSTRUCTIONS BEFORE STARTING INSTALLATION.
2. INSTALL IN ACCORDANCE WITH ALL LOCAL, STATE AND NATIONAL CODES CONSULT WITH A QUALIFIED ELECTRICIAN FOR PROPER INSTALLATION.
3. CAREFULLY UNPACK ALL CONTENTS; SOME COMPONENTS MAY HAVE BEEN SHIPPED IN SEPARATE BOXES MOST FIXTURES ARE SHIPPED PARTIALLY ASSEMBLED. SOME UNASSEMBLY MAY BE REQUIRED FOR INSTALLATION.
4. FIXTURE POWER CORD WIRES ARE LOW- VOLTAGE. DO NOT CONNECT TO LINE VOLTAGE OR DAMAGE TO THE FIXTURE WILL OCCUR AND WARRANTY WILL BE VOIDED.
5. DO NOT LET THE GLOWBALL LUMINAIRE HANG FREE UNTIL THE CABLE IS SECURED AND EVENLY TENSIONED.
6. KEEP HANDS AWAY FROM THE SILICONE DIFFUSER. DO NOT TOUCH IT AT ALL TIMES.

OCL Architectural Lighting

Phone: 314.863.1895
Fax: 314.863.3278
www.ocl.com

Table of Contents

GENERAL INFORMATION:	3
MOUNTING:	4
GLOWBALL MOUNTING [CANOPY]:	4
CORD INSTALLATION INSTRUCTIONS:	7

GB1-P1CF-INSTALLATION INSTRUCTIONS

GENERAL INFORMATION:

You will receive the following with each GLOWBALL series pendant fixture:

1. GLOWBALL LUMINAIRE with CORD attached. (Pre-assembled as shown in FIG. 2)
2. INSTALLATION INSTRUCTIONS (shown in FIG. 3) - Please completely read the install instructions before starting installation.
3. RED BAG (shown in FIG. 3) contains below following items
 - a. CANOPY
 - b. MOUNTING KIT CONTENTS (as shown in FIG. 4)
 - i. STRAIN RELIEF
 - ii. MOUNTING BRACKET ASSEMBLY
 - iii. FINIAL

WARNING: Examine all components for any damage before beginning installation.

WARNING: This fixture should be installed by a licensed electrician only.

WARNING: Be careful not to scratch or damage any finished parts.




FIG. 2 GLOWBALL LUMINAIRE (PRE-ASSEMBLED)




FIG. 3 RED BAG AND INSTALLATION INSTRUCTIONS




FIG. 4 MOUNTING KIT CONTENTS

OCL Architectural Lighting

Phone: 314.863.1895

Fax: 314.863.3278

www.oclighting.com

GB1-P1CF-INSTALLATION INSTRUCTIONS

MOUNTING:

GLOWBALL MOUNTING [CANOPY]:

1. Loosen the CANOPY FINIAL and remove CANOPY as shown in FIG. 5. Be careful not to scratch finish.
2. Unscrew the KNURLED NUT securing MOUNTING PLATE to driver MOUNTING BRACKET. Swing driver mounting bracket down and out of the way as shown below in FIG. 6.




FIG. 5 – CANOPY DIS-ASSEMBLY




FIG. 6 – MOUNTING PLATE DIS-ASSEMBLY

3. Attach MOUNTING BRACKET to JUNCTION BOX (by other) as shown below in FIG. 7.
4. Feed the CORD through FINIAL and CANOPY as shown below in fig. 8.




FIG. 7 – MOUNTING BRACKET ASSEMBLY INSTALLATION




FIG. 8 – CORD ASSEMBLY

5. Raise the GLOWBALL FIXTURE and pass the cord through MOUNTING BRACKET as shown below in FIG. 9. Adjust fixture drop to desired height. Mark cord with marker inside of DRIVER MOUNTING BRACKET as shown below in FIG. 10. Trim off excess cord leaving minimum of 8.00" past the top of the DRIVER MOUNTING BRACKET all thread.




FIG. 9 – FIXTURE INSTALLATION





FIG. 10 -CORD INSTALLATION



DETAIL A

OCL Architectural Lighting

Phone: 314.863.1895

Fax: 314.863.3278

www.oclighting.com

GB1-P1CF-INSTALLATION INSTRUCTIONS

- Insert cord through the strain relief and tighten two screws on the strain relief above hanging bracket where marked. If screws are not tightened properly, cord could slip through the strain relief causing the fixture to fall as shown in FIG. 11.



WARNING:

Do not let the GLOWBALL LUMINAIRE hang free until CABLE is secured and evenly tensioned.

TIGHTEN SCREWS ALL THE WAY



CORD

FIG. 11 – STRAIN RELIEF WITH CORD INSERTED

- Make wire connections between driver and fixture cord, all wire connections in the inside the junction box (by others) in accordance with the national electrical code and all applicable local and state codes. See wire diagram below in FIG. 14 for corresponding models and instructions on how to shorten/install the cord on page 7.
- Make wire connections between building supply and driver. See WIRE DIAGRAM as shown in FIG. 14 and WIRE LABEL TABLE below for wire connections. make all wire connections in accordance with the national electrical code and all applicable local and state codes.

WIRE DIAGRAM TABLE						
SERIES	HANGING SYSTEM	BODY SIZE	BODYLIGHT SOURCE	LED OUTPUT	CONTROL	WIRE DIAGRAM
GB1 : GLOWBALL	P1CF	04"	STATIC WHITE	LED1	0-10V DIM 1% (DM1)	WIRE DIAGRAM ON PAGE 6

DRIVER WIRES TO BUILDING SUPPLY

BLACK WIRE = LINE VOLTAGE
WHITE WIRE = NEUTRAL
GREEN WIRE = GROUND
PURPLE = DIM +
GREY = DIM -

FIG. 12 – WIRE CONNECTION FROM BUILDING SUPPLY TO DRIVER

WIRE LABEL TABLE

CONTROL	WIRE COLOR	LABEL
ALL	INSULATED(CORD)	LED(+)
ALL	BRAIDED(CORD)	LED(-)

FIG. 13 – WIRE CONNECTION FROM DRIVER TO FIXTURE CORD




FIG. 14 – WIRE DIAGRAM

OCL Architectural Lighting

Phone: 314.863.1895

Fax: 314.863.3278

www.ocllighting.com

GB1-P1CF-INSTALLATION INSTRUCTIONS

9. Swing DRIVER MOUNTING BRACKET back over and secure it with KNURLED NUT removed in step 3.
10. Raise CANOPY and secure to ceiling by threading the FINIAL to the NIPPLE (available in MOUNTING BRACKET ASSEMBLY) as shown below in FIG. 15.




FIG. 15 – FINIAL INSTALLATION

11. Restore power to circuit the GLOWBALL series pendant is connected to.
 - a. Test to see that the luminaire turns on after power is restored.
 - b. Contact OCL for any luminaire troubleshooting if a problem occurs.



FIG. 16 - COMPLETED INSTALLATION OF GLOWBALL
PENDANT WITH P1CF HANGING SYSTEM
GB1-P1CF-04-FS-XXX-LED1_XXK-UNV-XXX-DM1

OCL Architectural Lighting

Phone: 314.863.1895

Fax: 314.863.3278

www.ocl.com

CORD INSTALLATION INSTRUCTIONS:

- Strip off 1.00" of outer clear insulation exposing the outer metal braiding as shown in FIG. 17 below. **Be careful not to cut or damage the outer metal braiding.** Gently push braiding down to loosen the individual braids exposing the inner insulated wire as shown in FIG. 18 below.




FIG. 17




FIG. 18

- Using a small pointed object, begin unweaving the exposed metal braiding as shown in FIG. 19 below. Position the unwoven metal strands on one side of the inner insulated wire and twist the individual strands together as shown in FIG. 20 below.




FIG. 19




FIG. 20

- Using electrical tape, insulate the twisted strands leaving 0.188" exposed for connections. Strip off 0.188" of the inner insulation as you normally would for 18AWG stranded core wire as shown in FIG. 21 below. Connect the inner insulated wire (+) to the positive 16 gauge or larger wire ran in step 5 at the hanging bracket and Connect the outer braiding (-) to the negative 16 gauge or larger wire ran in step 5 at the hanging bracket FIG. 22 below.




FIG. 21




FIG. 22

OCL Architectural Lighting

Phone: 314.863.1895

Fax: 314.863.3278

www.oclighting.com